



Boeing 777-200 / -200LR / -300 / -300ER / F

Normal Checklist

Card 2/2 • Side A

BEFORE TAXI

L & R GENERATOR CONTROL SWITCHES	ON, LIGHTS OFF
APU SELECTOR SWITCH	OFF
ENGINE START SELECTORS	NORM
L & R PACK CONTROL SWITCHES	AUTO, LIGHTS OFF
L, C, R ISOLATION VALVE SWITCH	AUTO, LIGHTS OFF
ENG BLEED AIR SWITCHES	ON, LIGHTS OFF
FLAPS	SET __, CONFIRM
STABILIZER TRIM	SET __ UNITS
FLIGHT CONTROLS	FREE & CORRECT
RECALL SWITCH	CHECKED
WING / ENGINE ANTI-ICE	AUTO / AS NEEDED
TAXI LIGHT	ON
RUNWAY TURNOFF LIGHTS	AS NEEDED

BEFORE TAKEOFF

LANDING LIGHTS	ON
STROBE LIGHTS	ON
TRAFFIC MODE	TFC
CLOCK	RUN
TRANSPONDER MODE	TA/RA

AFTER TAKEOFF

LANDING GEAR	UP
AUTOBRAKE	OFF
ABOVE 10,000 FT	LDG LTS OFF
SEAT BELT SIGNS	AS DESIRED
TRANSITION ALTITUDE	SET STANDARD

DESCENT

FMC	VERIFY ARRIVAL / APPROACH
FLIGHT INSTRUMENTS (NAV, ALT, RADIOS)	SET
TRANSITION ALTITUDE	SET QNH
WING / ENGINE ANTI-ICE	AUTO / AS NEEDED
RECALL SWITCH	CHECKED
AUTOBRAKE	AS REQUIRED
LANDING DATA	VREF __, MINIMUMS __
APPROACH BRIEFING	COMPLETE



Boeing 777-200 / -200LR / -300 / -300ER / F

Normal Checklist

Card 2/2 • Side B

BEFORE LANDING

BELOW 10,000 FT	LDG LTS ON
SPEED BRAKES	ARM
SEAT BELT SIGNS	ON
ALTIMETERS	SET QNH

AFTER LANDING

LANDING LIGHTS	OFF
STROBE LIGHTS	OFF
TAXI LIGHT	ON
APU SELECTOR SWITCH	ON
WING / ENGINE ANTI-ICE	AUTO / OFF
AUTOBRAKE	OFF
SPEED BRAKES	DOWN
FLAPS	UP
TRANSPONDER MODE	STDBY

SHUTDOWN

PARKING BRAKE	SET
TAXI LIGHT	OFF
L & R ENGINE FUEL CONTROL SWITCHES	CUTOFF
SEAT BELT SIGNS	OFF
BEACON LIGHT	OFF
NAV LIGHT	ON
C1 & C2 AIR DEMAND HYDRAULIC PUMP SELECTORS	OFF
L ELEC DEMAND HYDRAULIC PUMP SELECTOR	OFF
PRIMARY C1 & C2 ELEC HYDRAULIC PUMP SWITCHES	OFF
R ELEC DEMAND HYDRAULIC PUMP SELECTOR	OFF
L & R FUEL PUMP SWITCHES	OFF
FLIGHT DIRECTOR SWITCHES	OFF
APU SELECTOR SWITCH	AS NEEDED

SECURE

ADIRU	OFF
EMER. EXIT LIGHTS	OFF
L & R PACK CONTROL SWITCHES	OFF
APU SELECTOR SWITCH	OFF
BATTERY SWITCH	OFF